



INSTALLATION INSTRUCTIONS FOR PART# AFX101 (REAR 2PC CENTER CAP)

1. Place the rear inner and rear outer wheel on the adaptor.
2. Place the ring with the 5 tabs on the face of the rear outer wheel and position each tab directly next to a wheel stud.
3. Torque down each lug nut to 400lbs and inspect installation. Each tab should be sandwiched between the wheel and lug nut.
4. Place the dome cap onto the ring and press into place.